

Goji

4,000mAh Qi Wireless Power Bank Pro

Instruction Manual

G6P4WL20




Thank you for purchasing your new product.

We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers. You will also find some hints and tips to help you resolve any issues.


Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Product Overview




Battery Status

Check the power level by pressing the **ON/OFF** button. Indicators will show the battery level.



Charging the Powerbank

While charging, the indicators will flash. When fully charged, the indicator will light up steadily.



The USB power adaptor output should matches the rated input of the powerbank.

Charging Your Digital Devices

Press the **ON/OFF** button to start charging if it does not start automatically.




Wireless Charging Digital Devices

1. Press the **ON/OFF** button to enable wireless charging. The wireless indicator will light up red.



The wireless charging feature will disable if it is not in use more than 60 seconds. Alternatively, press the **ON/OFF** button once to conserve battery.

2. Place your mobile device on the top of the powerbank. Both Qi sensors must overlap. The wireless indicator will light up green when succeeded.




- If the suction cups are not holding the mobile device firmly, wipe off the dust from their surface with a wet cloth and try again.
- When carrying or lifting, hold both the powerbank and mobile device in case the device falls.

Status	Wireless indicator
Charging	Light up in green
Fully charged	Light will turn off
Error	Flash in red and green, then light off.

Troubleshooting

If any functional abnormality is encountered, replace your mobile device on the unit.

- Mobile device is not placed in a correct position.
- Placing any metal or other item with electric field may cause short circuit, such as credit card, key, memory card, etc.
- The powerbank does not support small current devices (e.g. smartwatch, wireless earphones, etc.)
- The charging system is malfunction.



Specifications

Battery Type	Lithium ion
Capacity	4000 mAh
Input	5V \equiv 2A
Output	USB A: 5V \equiv 2.1A Wireless charging: 5V \equiv 1A (max. 5W) You may charge up to 2 devices at the same time, sharing a maximum 10.5W output current (2 x 5V \equiv 1A).
Frequency Band(s)	108 – 207 KHz
Max. Radio Frequency Power Transmitted	-37 dBuA/m @10m distance
Charge up the Powerbank	About 2.5 hours with input 5V \equiv 2A
Operating Condition	0°C – 35°C
Dimension (L x W x H)	128 x 67 x 13.5 mm
Net Weight	130 g

Features and specifications are subject to change without prior notice.

**Declaration of Conformity (RED)**

Hereby, DSG Retail Ltd. declares that the radio equipment type [G6P4WL20] is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

<https://www.teamknowhow.com/>

Click on **SEARCH** and enter the model number.